2021 to 2023

Q10072102 - ASRock J5040-ITX is UEFI-Only (no CSM). How can RAID adapter configure the RAID 1 without "Press F6" option during boot with the J5040-ITX.

McBIOS manager can be launched using UEFI Shell.

Please refer the faq Q10062102 - How to create a bootable USB drive to access the default UEFI shell to launch the McBIOS RAID manager?

Unique solution ID: #1951
Author: Simone
Last update: 2021-02-25 09:39

(c) 2024 Vincent C. <vincent_chen@abacid.com> | 2024-03-29 13:38
URL: http://faq.areca.com.tw//index.php?action=artikel&cat=8&id=952&artlang=en