

Q10031710 - Tried to install mraid-20170811 on MAC OS 10.13 (High Sierra) and the Installer status bar remains stuck.

Use the new installer (install_mraid-20170926.zip) to install APs and Driver.

Unique solution ID: #1716

Author: Simone

Last update: 2022-01-06 08:20