

Q10021702- ARC-1883 set to JBOD mode, after removing a disk, it would not beep.

Controller treats this as a free disk. It will not beep. ARC-1883 creates a pass-through disk, after removing this kind of disk, it would beep.

Unique solution ID: #1646

Author: Simone

Last update: 2022-01-06 08:16