

Q10061412 - Controller fails the brand new hard drive when runs the Hdd Xfer Speed function.

The problem is that the drive is not initialized, so it does not carry overwrite-repair a

ction on factory

bad bock and cause the read e

rrors. First, you must [initialize the drive](#)

, and then it will allow you to run Hdd Xfer Speed function.

Unique solution ID: #1170

Author: Simone

Last update: 2015-08-24 09:39