

Q10061312 - Expand the volume set, Windows does not show the added capacity. Windows shows original capacity before and after the expansion.

Volume expansion does not effect on the partition table. It expands the capacity of the volume only. You need to use the tool to add the unallocated space and resized the volume.

Unique solution ID: #1307

Author: Simone

Last update: 2015-08-24 11:26