Q10101307 - Updating to the latest Windows driver we found our system to be unbootable. How can we roll the driver back to the last version?

If your system can not start up by updating a device driver, you can roll the driver back to original version by press F8 while machine powers up, and chooses the 'Last working configuration' to start up the system with older version.

Unique solution ID: #1272
Author: Simone
Last update: 2015-08-24 10:32

(c) 2025 Vincent C. <vincent_chen@abacid.com> | 2025-07-04 11:50
URL: http://faq.areca.com.tw//index.php?action=artikel&cat=0&id=273&artlang=en