

Q10081308 - Is there a way to tell from the unix command line if the RAID controller is a -12, -16 or -24?

The port amounts are different between these models, so you can use disk info command to find out which card you have.

Unique solution ID: #1280

Author: Simone

Last update: 2015-08-24 10:37