

Q10011510 - Is it possible to enable the Areca RAID controllers encryption function on the boot volume?

The volume encryption feature works on data volumes only, not the system volume.

Unique solution ID: #1500

Author: Simone

Last update: 2015-10-08 04:35