

2018 to 2020

Q10051410 - How to set the CLI instant volume check function 'scrub bad block' and 'recompute parity' option. It is possible via WebGUI.

Cli does not support the option setting. Both 'scrub bad block' and 'recompute parity' are enabled via an instant volume check.

Unique solution ID: #1149

Author: Simone

Last update: 2015-08-24 09:36