

**2018 to 2020**

# **Q10071808 - Why enable the “Read And Discard Parity Data” option on the ‘Advanced Configuration” to improve the read performance.**

The “**Read And Discard Parity Data**” is used to determine if parity data is to be read and discarded. Enable this setting has better read throughputs mean this drive has no good performance in array applications. For this kind of drives, enable this setting can improve the read performance and have no side effect.

Unique solution ID: #1765

Author: Simone

Last update: 2022-01-06 07:51