

**2018 to 2020**

**Q10031910 - I have started to use the areca RAID adapter build in Ethernet port. I can log in to telnet and http. How do I restrict access to the telnet port or SMTP?**

To disable the telnet port or http port, just configure it as port 0. If you didn't configure the SMTP IP setting, it will be not used.

Unique solution ID: #1800

Author: Simone

Last update: 2020-08-25 10:46