

Q10031001 - System will not get past ARC-1680ix card bios boot screen when plugged into Promise e610p raid array using external SAS connector. When the cable is unplugged during boot system gets to windows fine. System runs fine as long as it is not connected to the raid array.

Intel IOP348 can work with one lane for the external RAID subsystem. It can create the volume on Lun0 and volume limitation on the 2TB.

Unique solution ID: #1449

Author: Simone

Last update: 2022-01-06 07:59