

**Q10060902- I have a ARC-1220, in a server running FreeBSD 6.1, but I can not get the HD's temperature using the application cli32, I try to use the http proxy but also did not get the expected result.**

Controller can get the HDD temperature through CLI; the SMART polling feature in controller setting must be enabled. Please also make sure your system have latest controller driver and CLI versions. Because some new added features need latest firmware, driver and utility supported.

Unique solution ID: #1517

Author: Simone

Last update: 2022-01-06 07:56