

Q80042102 - Is there a way to config the ARC-8050T3U-6 installed 6 HDDs to recognize each HDD separately within my OS?

You can configure the raid box to JBOD mode. The raid box will automatically configure all connected drives as pass-through disks in JBOD mode. You can find JBOD/RAID Configuration feature in System Controls menu, the default setting is RAID mode.

Please note, only thunderbolt port support multiple devices, you can see all 6 drives through thunderbolt connection only.

Unique solution ID: #1947

Author: Simone

Last update: 2021-02-24 10:37