

Q80021607 - ARC-8050T2 has been working perfect up until last week it keeps rebooting itself.

It may be caused by bad cable or port connection. You validate with another cable and the other port to isolate the reason.

Unique solution ID: #1618

Author: Simone

Last update: 2022-01-06 07:31