

2016 to 2020

Q50011404 - How to daisy chain two ARC-8028 with ARC-1883X?

External cable connector: i, j, k,.. is the index which range from 0 to 3 on the ARC-8028. According to view from connector side, index start from right to left or top to bottom. The cable c0, c1, or c2 is view from right to left or start from top to bottom. Use the "sub" command to assign connector c0 and c1 as subtractive ports for ARC-1883X two external outputs.

```
CLI>sub
```

Current Subtract Connector: C1,

;;; set connector c0 and c1 as subtractive ports

```
CLI>sub c0,c1
```

New Subtract Connector: C0,C1,

Current Subtract Connector: C1,

```
CLI>st
```

```
CLI>reset
```

Unique solution ID: #1202

Author: Simone

Last update: 2021-02-04 10:37