

2016 to 2020

Q50021907 - How to identify the cable is active or not?

Use the AOC cable plug ARC8028 and ARC8026. From ARC8028 CLI prompt, issue the following commands

```
CLI>>cable
```

Current Cable management: Off

```
CLI>>cable on ;;;turn cable management on
```

New Cable management: On

```
CLI>>st
```

All Of The User Configurations are Saved.

```
CLI>>reset
```

Unique solution ID: #1831

Author: Simone

Last update: 2021-02-04 10:41