

Q80041312 - When I force power the 5026 without any cable connected other than the power supply or USB 3.0 host connects only: it goes to and stays on the "start the kernel" message.

This is a bug of ARC-5026 working at AJA mode (Optimize AV Recording=Mode 3). It can be fixed by firmware version 1.52 date:2013-12-11 or later.

Unique solution ID: #1330

Author: Simone

Last update: 2022-01-06 07:13