

Q60011503 - How to connect ARC-5020 through iSCSI to windows 7 Enterprise?

Please make sure the volume configured with correct Ch#/Drv#.

For iSCSI connection, volumes must be configured with Ch1 (USBiA), and the Drv# must be 8-15). Reboot ARC-5020 once to activate the new setting after change the setting. ARC-5020 does not support CHAP feature on iSCSI initiator setting, please make sure the CHAP feature is disabled.

Unique solution ID: #1058

Author: Simone

Last update: 2022-01-06 07:06