

**2016 to 2020**

**Q80042009 - When I look at Events in ArcSAP I see that the Raid is powering on every 3 minutes or so.**

Please check the OS power saving settings to see if the OS may spin down drives after 3 mins idle. Raidbox will be turn off when OS spin down arrays.

Unique solution ID: #1925

Author: Simone

Last update: 2022-01-06 07:22