

Q60011311 - How do I enable ARC-5040 USB 3.0? USB 2.0 works but when plugged in via USB 3.0 the access light only flashes. No device is made available to the OS.

USB 2.0 and 3.0 use different configurations, please make sure you properly configure volumes and controller setting.

USB 2.0 port mapping to volumes with channel 1, driv 0-7

USB 3.0 port mapping to volumes with channel 0, driv 8-15, and the 'USB3.0/1394 Select' setting must configure change to USB 3.0.

Unique solution ID: #1313

Author: Simone

Last update: 2021-02-04 10:49