

Q10052102 - The server doesn't load the areca BIOS in Legacy mode. Quiet boot = off, Oprom for all PCI slots are set to legacy, boot type is legacy.

The "secure boot" has to be enabled in the main-board BIOS.

Unique solution ID: #1940

Author: Simone

Last update: 2021-02-04 09:32