

2010 to 2015

Q50011203 - To make use of the LSI SAS switch 6160's zoning features, it need to have the passwords on the 6160 and the ARC-8026 match.

What is the ARC-8026 zoning password?

CLI function password is different from Zone administration password. Our expander zoning password is "0123456789ABCDEF". You can modify this inband management password in case you have security concern.

Unique solution ID: #1370

Author: Simone

Last update: 2021-02-04 10:37