

# **2009 to 2011**

## **Q10060906 - Areca PCIe RAID adapter BIOS screen does not post during boot on Intel DG31PR and DG45ID motherboards. Is there a fix?**

Enable "expansion card text" under SECURITY on Intel BIOS option.

Unique solution ID: #1533

Author: Simone

Last update: 2022-01-06 07:58