

**2009 to 2011**  
**Q10060906 - Areca PCIe RAID adapter BIOS**  
**screen does not post during boot on Intel**  
**DG31PR and DG45ID motherboards. Is there a**  
**fix?**

Enable "expansion card text" under SECURITY on Intel BIOS option.

Unique solution ID: #1533

Author: Simone

Last update: 2022-01-06 07:58