

**2010 to 2015**

**Q60021208 - I plug the ARC-5040 box USB 3.0 port into a system with USB 3.0 support. The access light starts blinking and never stops. I want the LED light-up only when there is HDD activity.**

It has fixed by firmware date: 2012-03-05 or later. This firmware has removed both (busy LED on the LCD) and USB 3.0 LED (Host access LED).

Unique solution ID: #1374

Author: Simone

Last update: 2015-08-24 06:16