

2011 to 2015

Q10131403 - Locate and identify drives in an enclosure or backplane with Fault/Activity LEDs.

You can use the "Identify Selected Drive" on Areca RAID controllers to locate and identify drives by flashing fault LED in an enclosure or backplane.

Unique solution ID: #1223

Author: Simone

Last update: 2015-08-24 08:26