2018 to 2020

Q10031805 - ARC-1883LP is booting without any problem in lagacy mode. But if I try to configure it in UEFI mode the system doesn´t start any more.

The supported partition table for both legancy and UEFI mode is different. If your OS can boot up under Legacy mode, it will not boot up under UEFI mode.

Unique solution ID: #1746
Author: Simone
Last update: 2022-01-06 07:40

(c) 2024 Vincent C. <vincent_chen@abacid.com> | 2024-03-29 01:49
URL: http://faq.areca.com.tw//index.php?action=artikel&cat=10&id=747&artlang=en