

**2009**

**Q10060906 - Areca PCIe RAID adapter BIOS screen does not post during boot on Intel DG31PR and DG45ID motherboards. Is there a fix?**

Enable "expansion card text" under SECURITY on Intel BIOS option.

Unique solution ID: #1533

Author: Simone

Last update: 2015-10-16 11:58