

2018

Q80021811 - iMac Pro can't detect RAID drive as bootable device.

Please choose the right OS settings for booting from external device.

<https://support.apple.com/en-us/HT208198>

Use Startup Security Utility to make sure that your iMac Pro always starts up from your designated startup disk, and always from a legitimate, trusted operating system.

Available only on iMac Pro, Startup Security Utility offers three features to help secure your Mac against unauthorized access: [Firmware password](#) protection, [Secure Boot](#), and [External Boot](#).

To allow your iMac Pro to use an external startup disk:

1. Update OS to macOS 10.14 Mojave
2. [Open Startup Security Utility](#).
3. Select "Allow booting from external media."
4. If you want to select an external startup disk before restarting your Mac, quit Startup Security Utility, then choose Apple () menu > Startup Disk.



Unique solution ID: #1796
Author: Simone
Last update: 2019-01-03 11:19