

**2015**

## **Q80061403 - I can not access a new encrypted volume on ARC-8050T2.**

An encrypted volume can be accessed by OS when

1. Foreground initialization has completed.
2. Volume has been unlocked.

Once a volume has been created with encryption enabled, you must generate key file by cli firstly. With this key file, you can unlock the encrypted volume in web manager.

You can refer the page 59 in user manual for more detail about how to use encrypted volumes.

Unique solution ID: #1231

Author: Simone

Last update: 2015-08-24 08:27