

Q10061412 - Controller fails the brand new hard drive when runs the Hdd Xfer Speed function.

The problem is that the drive is not initialized, so it does not carry overwrite-repair action on factory bad bock and cause the read errors. First, you must [initialize the drive](#), and then it will allow you to run Hdd Xfer Speed function.

Unique solution ID: #1581

Author: Simone

Last update: 2016-02-16 05:09