Q10052102 - The server doesn't load the areca BIOS in Legacy mode. Quiet boot = off, Oprom for all PCI slots are set to legacy, boot type is legacy.

The "secure boot" has to be enabled in the main-board BIOS.

Unique solution ID: #1940
Author: Simone
Last update: 2021-02-04 09:32

(c) 2024 Vincent C. <vincent_chen@abacid.com> | 2024-03-28 21:50
URL: http://faq.areca.com.tw//index.php?action=artikel&cat=0&id=941&artlang=en